



NOTE: ALL SAWN LUMBER FLOORS SHALL BE BLOCKED AT 8'-0" O.C. MINIMUM

SECOND FLOOR FRAMING

FIRST FLOOR FRAMING PLAN

scale: 1/4" : 1'-0"